

- 1) Disassemble Fuel Pump Elbow Set, as it is supplied. (as shown in Figure B.)
- 2) Move cap nut and compression sleeve to positions shown in Figure A.
- 3) Tighten cap nut on fuel pump fitting. Be careful not to over-tighten.
- 4) Thread hose on elbow, again being careful not to over-tighten.

## MOSS MOTORS, LTD.

P.O. Box 847 440 Rutherford Street Goleta, California 93117 (800)235-6954 FAX (805)692-2525