

Supplemental Information & Instructions
for
021-362 or AEC1341 Oil Pump, Gear Type
BN7& BT7 FROM E29D-H895, BJ7, BJ8

About this Pump

The original pumps are long gone, and we are fortunate to have a replacement pump available. The manufacturer assembles these pumps from hand selected components to achieve the tolerances recommended by the factory. Each pump is individually tested to ensure that they perform as they should. They are assembled with motor oil.

Before you install this pump, it should be primed completely with motor oil.

The manufacturer has stated "Under no circumstances should the pump be dismantled as this may upset the alignment of the shafts and base plate."



For complete instructions on replacing your oil pump, please refer to your workshop manual.



Moss Motors, Ltd.

440 Rutherford Street, Goleta, California 93117

In the US & Canada Toll Free (800) 667-7872 FAX (805) 692-2510 (805) 681-3400

Moss Europe Ltd.

Hampton Farm Industrial Estate, Hampton Road West, Hanworth Middlesex, TW13 6DB

In the UK: 020-8867-2020 FAX:- 020-8867-2030

Instruction Sheet 021-362_AEC1341 August 2007